



## C128 DIAGNOSTIC SPECIFICATION

### Table of contents:

1. Introduction
2. General flow chart
3. Description for each tests
4. Error code list
5. Screen format

### 1. Introduction

How to use the diagnostic-program.

To run the diagnostic-program you need the diagnostic-box with a set of jumper plugs. The diagnostic box contains all software-routines and will start automatically.


Plugs and box have to be installed on the switched-off machine. Then switch on.

If the diagnostic-program indicates parts as bad, first step should be to test the voltages at the part.

To find out which signal lines are tested in the test routines, one should look at the wiring of the jumpers, the schematics of the machine and schematics of the diagnostic box.



2. General flow chart



\* always todos are displayed



### 3. Description

#### 1) RAM TEST

Diag check both RAM bank 0 and 1.

When 1, also color RAM bank 1.

Color/RAM bank 0 is initialized blue, 1 is orange.

You can know collent bank by character color.

##### (1) Zero Page (addr $02_H$ - $FF_H$ )

at first, write  $80_H$  (MSB=1) to RAM,  
and read verify for performed.

Then shift right 1 Bit, repeat.

Shift 8 Bit IS 1 cycle per 1 byte.

##### (2) Stack Page (addr $100_H$ - $1FF_H$ )

Same as Zero Page test.

##### (3) RAM test 1 (addr $200_H$ - $2FFF_H$ )

Fill by check data and read verify for performed.

There are 4 kind (type) of data-pattern.

Datas as following;

$00_H$ ,  $55_H$ ,  $AA_H$ ,  $FF_H$

#### 2) Z80 ROM TEST

Switch for Z80 mode.

Calculate BIOS ROM (addr  $0000$  -  $0FFF_H$ ) signature  
and compare correct value in the table.

Return to 8502 mode.



3) VDC RAM TEST

(1) Block write

Write data  $00_H$  to first 128 bytes.

(2) Block copy

Copy from source of first 128 bytes to next 128 bytes,  
127 times.

Same as fill all video RAM / COLOR RAM  
by  $00_H$  data.

Video RAM 8K / COLOR RAM 8K

(3) V/C RAM TEST

Fill all C/U RAM by check data  
and read verify for performed.

Data-pattern as following;

$00_H$ ,  $55_H$ ,  $AA_H$ ,  $FF_H$

4) RAM TEST 2

(1) RAM TEST 2 (addr  $4000_H$  -  $FFFF_H$ , skip MMU)  
same as RAM test 1

(2) Color RAM test (addr  $D800_H$  -  $DBFF_H$ , bank 0, 1)  
Same as RAM test 1  
and restore collent color code.

5) Interrupt

Check if the interrupt of 6526 (U1, U4) is normal.



6) ROM TEST

ROM check sum; add carry and add last carry

1	addr	4000 <sub>H</sub> - 7FFF <sub>H</sub>	LO (BASIC LO)	U33
2	addr	8000 <sub>H</sub> - BFFF <sub>H</sub>	MID (BASIC HI)	U34
3	addr	C000 <sub>H</sub> - CFFF <sub>H</sub>	HI (EDITOR)	U35
4	addr	D000 <sub>H</sub> - DFFF <sub>H</sub>	CHARACTER(128)	U18
5	addr	E000 <sub>H</sub> - FFFF <sub>H</sub>	HI (KERNAL)	U35

7) TIMER

Check 6526 Timers: U1 timer A/B and U4 timer A/B.

8) I/O TEST

Check if I/O port is normal.

- (1) Cassette Test
- (2) Keyboard Test
- (3) Control Port Test
- (4) Serial Port Test
- (5) User Port Test

Add test as following;

- (1) I/O TEST  
Cartridge port I/O 1, I/O 2, HI ROM line
- (2) KEYPORT TEST  
Add VIC chip keyport test
- (3) FAST SERIAL  
CIA SP (serial data), DNT (serial srqin) line  
(cut user's port SP.CNT TEST)

Please refer C128 diag schematics



- 9) SOUND TEST  
To be confirmed by "ear".
  
- 10) SCREEN DISP (COLOR PATTERN)
  - (1) Border/Background 16 Pattern Test
  - (2) Vertical and horizontal stripes display
  - (3) Display all colors (16 colors), one color per a byte
  - (4) Display all colors every two lines
  
- 11) RANDOM OSC (SID)  
Routine will show Asterix on screen which will be found with random generator.
  
- 12) C64 ROM  
C64 ROM check sum (BASIC/CHARACTER/KERNAL)
  
- 13) TOD  
  
Display the clock of 6526 (U1, U4)  
  
(Display when the screen is renewed)





- ROM ERROR

- 1 = ROM LO (BASIC LO) U33
- 2 = ROM MID(BASIC HI) U33
- 3 = ROM HI (EDITOR) U35
- 4 = CHAR ROM (C-128) U18
- 5 = ROM HI (KERNAL) U35
- (0) = INTERNAL FUNCTION U36

- TIMER ERROR

- 1 = LO LIMIT (TIMER TOO FAST)
- 2 = TIMER OUT



- I/O PORT ERROR

NG : CARTRIDGE SLOT  
I/01, I/02, HIROM


- CASSETTE ERROR

- 1 = CAS SENSE OR SERIAL SRQIN
- 2 = CAS MOTOR OFF OR +5V IS NOT SUPPLIED FOR TEST FIXTURE
- 3 = CAS MOTOR ON



- KEY PORT ERROR (CIA1)







- CONTROL PORT ERROR



- SERIAL PORT ERROR

- 1 = DATA(OUT) / SRQIN
- 2 = DATA(OUT) / DATA(IN)
- 3 = ATN,CLK(OUT) / CLK(IN)

- FAST SERIAL ERROR

- 1 X : CIA1 -- CIA2
- 2 X : CIA2 -- CIA1

- A = SP OUT OR TIMER A/CNT (SP SEND FAIL)
- B = SP OUT CNT OR SP IN CNT (SP RECEIVE FAIL)
- C = SP OUT SP OR SP IN SP (SEND/RCV DATA MISMATCH)

(SP = SER DATA / CNT = SER SRQIN)



- USER'S PORT ERROR


1 : ATN, PA2

2 X X : B PORT

    |  |  
    |  | IN DATA  
    |  |  
    |  | OUT DATA

3 : PC2, FLAG2






commandant  
-C128 DIAG  
TEST FIXTURE

DATE	12-12-12
BY	
CHKD BY	
APPROVED BY	
TESTED BY	
TESTED DATE	

KEY BOARD, CONTROL PORT 1/2, CASSETTE PORT  
VIDEO PORT, SERIAL BUS PORT, USER PART, PORT BOARD PART

PC-E-C-2-A-1-A1



KEY BOARD, CONTROL PORT 1/2, CASSETTE PORT  
 VIDEO PORT, SERIAL BUS PORT, USER PORT, ROM BOARD PORT

DATE	DESIGNED BY	COMMODORE
		C128 DIAG
		TEST FIXTURE
		12.12

C128-002-013 AF